

**Contents Page**

	<u>Page</u>		
Introduction	I		
Safety	III		
Torque chart	IV		
Bolt Finder	V		
Getting Started	VI		
Contents	VII		
1. Aluminium Panelling	1	7. Fuel Tank & Supply System	51
Standard Panel Kit	1	Inertia Switch	51
Lowered Floor	2	Fuel Tank	52
Fitting Panels	3	Fuel Pump & Filter	54
Panel Fitting Order	4		
 		8. Inertia Seat Belt Reels	57
2. Pedal Area	7	9. Speed Transducer	59
Standard Pedal Layout & Options	8	VDO Gauge Transducer	59
Brake Master Cylinder Options	9	Smiths Gauge Transducer	60
Standard Hydraulic Clutch	10		
Cable Clutch	11	10. Upper Steering Column	61
Standard & AP Single Cylinders	12	11. Windscreen Washer Bottle	63
Bias Brake Twin Master Cylinders	13		
Standard Accelerator Pedal	14		
Brake Pressure Switch	15		
Break Pipes	16		
Fuel Pipes	18		
3. Wiring Loom	25		
Mounting The Wiring Loom	25		
Routing The Loom	27		
4. Front Suspension & Steering Rack	31		
Standard & Wide Track Suspension	31		
Front Wishbones	32		
Shock Absorbers	34		
Steering Rack	35		
Front Upright	37		
5. Rear Suspension & Differential	39		
Wishbones	40		
Shock Absorbers	40		
Rear Upright	41		
Rear Brakes	42		
Differential Housing	43		
Driveshafts	45		
6. Handbrake & Flexible Rear Pipes	47		
Handbrake Lever	47		
Handbrake Cable	47		
Rear Flexible Brake Pipes	49		

