


**Bolt Length** – Actual Size**Metric Bolts**

16mm
20mm
25mm
30mm
35mm
40mm
45mm
50mm
55mm
60mm

**Imperial Bolts**

4"
3 3/4"
3 1/2"
3 1/4"
3"
2 3/4"
2 1/2"
2 1/4"
2"
1 3/4"
1 1/2"
1 3/8"
1 1/4"
1"

Bolt Diameter – Actual Size

M5	M6	M8	M10	M12	7/16"

Notes

- The difference between a **BOLT** and a **SETSCREW** is that a bolt is only partially threaded and has a plain upper section, whereas a setscrew is threaded along its whole length.
- The length of a bolt or a setscrew is measured from the underside of the head.
- The diameter of a bolt is measured across the plain non-threaded section, for a setscrew measure across the top of the threads.



Getting Started

If you have purchased the optional Westfield chassis support stands then, with the help of an assistant, lift and position the chassis onto these supports.

If you have not purchased these stands, then ensure that the chassis is positioned onto suitable supports, which allow the various parts to be fitted.

Important - Do not attempt to modify any of the items supplied without specific reference to the technical helpline at the factory

Storage of bodywork

- The bodywork **must not** be stored in plastic sheet, in damp or humid conditions.
- **Do not** store bodywork in direct sunlight, in greenhouses or conservatories

Westfield Sportscars will not accept warranty claims for damage to bodywork where the damage has been caused by any of the above conditions.