



10 Upper Steering Column

The upper steering column, steering wheel complete with collapsible steering wheel boss and energy absorbing steering wheel cover as supplied by Westfield complies with the SVA regulations.

The upper steering column comes complete with steering lock and the ignition barrel.

Regardless of left or right hand drive, the fitting procedure is the same.



Tools Required

Torque Wrench
13mm Spanner
13mm Socket

Fitting the Upper Steering Column

1. Locate the upper steering column on the chassis brackets, so the ignition barrel is hanging below the column. The column needs to go under the lower chassis mount.

2. Attach at the top mount loosely at first using, place the bolts up through the mount with nuts on top.

- 2 x 20mm long x 8mm bolt
- 4 x 8mm plain washer
- 2 x 8mm nyloc nit



3. Place the aluminium spacer provided between the lower column mount and the chassis mount. Attach by placing the bolts down through the chassis mount

- 2 x 35mm long x 8mm bolt
- 4 x 8mm plain washer
- 2 x 8mm nyloc nit



4. Align the column and torque all bolts to 27n/m (20 ft/lbs)

